



<p><b>1.</b></p> <p>#12-24 mounting screws</p> <p>Attach screws to rear of panel.</p>	<p><b>2.</b></p> <p>Mount strain relief bar.</p>
<p><b>3.</b></p>	<p><b>4.</b></p> <p>Use Tak-Ty Hook &amp; Loop Cable ties for cable management.</p>