© Panduit Corp. 2012-2015 **INSTALLATION INSTRUCTIONS** **CM608A**

PDU Bracket Kit Installation *(optional)*

- Install [4] M5 Torx Screws into desired top location of cabinet post, as shown below
- Do not tighten screws - Leave a gap between screw and cabinet post for bracket thickness
- Place Top PDU Bracket over screw heads and slide up *(or down, depending on mounting side of cabinet)*
- Install Bottom PDU Bracket at desired distance from Top PDU Bracket
- Tighten [8] M5 Torx Screws



DO NOT TIGHTEN
(Leave Gap Between Screw and Cabinet Post)

[4] M5 Torx Screws
(use T25 Torx bit)



LEFT SIDE:
Slide down

RIGHT SIDE:
Slide up



PDU Bracket
(installed)



NOTES:

- Panduit recommends installation of NVPDUB brackets prior to positioning of cabinets in row
- An angle impact driver (such as Makita® BTL061) is recommended when installing NVPDUB brackets on cabinet positioned in row